



CN0009
3P
WHT
:N1N1

1	DGC
2	NC
3	DGC

CN0703 5P
GRY :VH

1	AC 1N
2	
3	
4	
5	AC 1N

TO D BOARD
CN0723

CN0701 10P
GRY :BTOB-P

1	GND
2	GND
3	GND
4	GND
5	GND
6	GND
7	GND
8	GND
9	GND
10	GND

TO D BOARD
CN0101

CN0058 2P
WHT
:N1N1

1	DGC
2	CHK

CN0702 20P
B-T-O-B

1	6.5B
2	6.5B
3	6.5B
4	10B
5	135B
6	13.5B (KICK)
7	GND (PROTECT)
8	SOFT START
9	+22B (AUDIO)
10	GND
11	+22B (AUDIO)
12	GND
13	GND (AUDIO)
14	GND
15	GND (AUDIO)
16	GND
17	+22B (AUDIO)
18	GND
19	+22B (AUDIO)
20	ST CONT
21	STB 5B
22	PROTECT

Q621 - 2SC2500-B
RELAY SW
Q601 - 2SC4834NP
PROTECT
Q602 - 2SC4834NP
PROTECT
Q603 - JC501TP-Q
PROTECT
Q604 - 2SC2500-B
PROTECT